



Attention!
this side please
downward.

WARN:
Loose the steel sheet U
NUT to adjust angle,
if necessary. Screwed over
steel sheet U NUT.



FS1040

Item	Spare parts	Q'ty
1	MATCHED PLATE	1
2	FIXED TUBE	1
3	EXTENSION TUBE L=1000mm	2
4	LEFT BOTTOM TUBE	1
5	RIGHT BOTTOM TUBE	1
6	PLASTIC COVER	2
7	WHEEL	4
8	TOP COVER \varnothing 50.8	4
9	TOP COVER \square 45*45	2
10	FIXED PLATE	2
11	WASHER \varnothing 8.5* \varnothing 25*T3	2
12	STATURE ADJUSTMENT	1
13	NYLON NUT 5/16"-18UNC	2
14	SCREW BH 3/8"-16UNC*L58mm	2
15	SCREW CAP 5/16"-18UNC*L3/4" +2 WASHERS	20



A	T-HANDLE (L=180)	1
B-1	SCREW M4*L12 FOR LCD	4
B-2	SCREW M5*L15 FOR LCD	4
B-3	SCREW M6*L15 FOR LCD	4
B-4	SCREW M8*L15 FOR LCD	4
C-1	SCREW M4*L35 FOR PDP	4
C-2	SCREW M5*L35 FOR PDP	4
C-3	SCREW M6*L35 FOR PDP	4
C-4	SCREW M8*L35 FOR PDP	4
D-1	SPRING WASHER ϕ 4 FOR PDP	4
D-2	SPRING WASHER ϕ 5 FOR PDP	4
D-3	SPRING WASHER ϕ 6 FOR PDP	4
D-4	SPRING WASHER ϕ 8 FOR PDP	4
E	SLEEVE ϕ 8.5* ϕ 15*L20mm FOR PDP	4
F-1	WASHER ϕ 6* ϕ 18 FOR PDP	4
F-2	WASHER ϕ 8* ϕ 18 FOR PDP	4
G	WRENCH NO.17	1